



Seagate SSD Touch User Manual

© 2020 Seagate Technology LLC. All rights reserved. Seagate, Seagate Technology, the Spiral logo, and LaCie logo are trademarks or registered trademarks of Seagate Technology LLC or one of its affiliated companies in the United States and/or other countries. When referring to drive capacity, one gigabyte, or GB, equals one billion bytes and one terabyte, or TB, equals one thousand billion bytes. Your computer's operating system may use a different standard of measurement and report a lower capacity. In addition, some of the listed capacity is used for formatting and other functions and will not be available for data storage. Quantitative usage examples for various applications are for illustrative purposes. Actual quantities will vary based on various factors, including file size, file format, features, and application software. The export or re-export of hardware or software containing encryption may be regulated by the U.S. Department of Commerce, Bureau of Industry and Security (for more information, visit www.bis.doc.gov) and controlled for import and use outside of the U.S. Actual data rates may vary depending on operating environment and other factors. Complying with all applicable copyright laws is the responsibility of the user. All coded instruction and program statements contained herein is, and remains copyrighted works and confidential proprietary information of Seagate Technology LLC or its affiliates. Any use, derivation, dissemination, reproduction, or any attempt to modify, reproduce, distribute, disclose copyrighted material of Seagate Technology LLC, for any reason, in any manner, medium, or form, in whole or in part, if not expressly authorized, is strictly prohibited. Seagate reserves the right to change, without notice, product offerings or specifications.

Seagate Technology LLC
47488 Kato Road
Fremont, CA 94538 U.S.A

Seagate Technology (Netherlands) B.V.
Koolhovenlaan 1
1119 NB Schiphol-Rijk
The Netherlands



Click here to access an up-to-date online version
of this document. You will also find the most recent content as well as expandable illustrations, easier navigation, and search capability.

Singapore 737911

Contents

1 Seagate SSD Touch	3
Requirements	3
Menus and options	3
Selecting a device	4
Viewing folders and files	5
• View options	5
Selecting multiple folders and files	5
• Select All	5
Backing up media	5
Creating new folders	6
Opening files	6
Copying folders and files	6
Moving folders and files	7
Sharing files	7
Duplicating folders and files	7
Deleting folders and files	8
Viewing file and folder information	8
Renaming a folder or file	8
Viewing notifications	9
Viewing configuration settings	9

Seagate SSD Touch

Seagate SSD Touch lets you manage files stored on compatible Seagate devices using your Android mobile device. Use SSD Touch to:

- Back up files from your Android mobile device to your Seagate device.
- Move, copy, share, and delete files and folders on your Seagate device and Android mobile device.

Supported devices	Product support page	User manual
Seagate Ultra Touch SSD	Product	Documentation


Requirements

Seagate SSD Touch requires Android 8.0 and higher.



SSD Touch has been tested with a number of Android devices. Many mobile devices with Android 8.0 and higher allow for connectivity to external storage devices, however, Seagate cannot guarantee that all Android mobile devices will work with your storage device.

Menus and options



1. Navigation
2. More
3. View
4. New folder
5. Actions

Selecting a device

Use the Navigation menu to select Ultra Touch or your mobile device.

1. Tap the Navigation icon.
2. Tap Ultra Touch or a device to select it.



You can also open the Navigation menu using a gesture to slide it out from the left side of the screen.

Viewing folders and files

Tap a folder or file to open it. Use the Back Arrow to navigate to the previous folder.

View options

Use the View icons to switch between thumbnail and list views.



Tap to view folders and files as thumbnails.



Tap to view folders and files as lists.

You can also choose the criteria by which files are sorted in SSD Touch.

1. Tap the More icon.
2. Tap [Sort](#).
3. Select the sort criteria: [Name](#), [Date Modified](#), [Size](#), [File Type](#), or [File Kind](#).
4. Tap the sort order: [Ascending](#) or [Descending](#).

Selecting multiple folders and files

You can select multiple folders/files for certain actions:

- Sharing files
- Copying folders and/or files
- Moving folders and/or files
- Deleting folders and/or files

Use standard Android conventions for selecting multiple items:

1. Long press to select a file or folder. A checkmark appears next to the selected item.
2. Repeat to select additional files or folders.

Select All

To select all files and folders on the screen, open the More menu and tap [Select All](#).

Backing up media

Use SSD Touch to back up different categories of media on your mobile device:

- Photos and Videos
- Music
- Documents

To back up media:

1. Tap the Navigation icon.
2. Tap [Backup](#).
3. Select the media categories you want to back up.
4. Tap [Back Up Now](#).

Creating new folders

To add new folders:

1. Tap the New Folder icon.
2. Use the virtual keyboard to enter a name for the new folder.
3. Tap [Create](#).

Opening files

To open files with an appropriate app for the selected file type:

1. Tap the Actions icon next to a folder or file.
2. Tap [Open with](#).
3. Select an app.

Copying folders and files

To copy a single folder or file from one location to another:

1. Tap the Actions icon next to a folder or file.
2. Tap [Copy](#).
3. Select a destination folder for the copy. (If you're copying from one device to another, tap the Navigation icon to select the other device, then navigate to the destination folder.)
4. Tap [Copy Here](#).

To copy multiple folders and/or files:

1. Select the folders and files you want to copy.
2. Tap the Copy icon.
3. Select a destination folder for the copy. (If you're copying from one device to another, tap the Navigation

icon to select the other device, then navigate to the destination folder.)

4. Tap [Copy Here](#).

Moving folders and files

To move a single folder or file from one location to another:

1. Tap the Actions icon next to a folder or file.
2. Tap [Move](#).
3. Select a destination folder for the move. (If you're moving from one device to another, tap the Navigation icon to select the other device, then navigate to the destination folder.)
4. Tap [Move Here](#).

To move multiple folders and/or files:

1. Select the folders and files you want to move.
2. Tap the Move icon.
3. Select a destination folder for the move. (If you're moving from one device to another, tap the Navigation icon to select the other device, then navigate to the destination folder.)
4. Tap [Move Here](#).



Canceling a move—When a move is voluntarily canceled, the action is considered to be stopped. All files remain in the original location.

Sharing files

To share a single file on social media:

1. Tap the Actions icon next to a file.
2. Tap [Share](#).
3. Select the app or feature you want to use to share the file.
4. Follow the onscreen instructions.

To share multiple files:

1. Select the files you want to share.
2. Tap the More icon.
3. Tap [Share](#).
4. Select the app or feature you want to use to share the file.
5. Follow the onscreen instructions.

Duplicating folders and files

To duplicate a folder or file:

1. Tap the Actions icon next to a folder or file.
2. Tap **Duplicate**.

The duplicated folder or file is added to the same location as the original, using the same name plus an underscore character (_) and a number, for example, _1.

Deleting folders and files

To delete a single folder or file:

1. Tap the Actions icon next to a file.
2. Tap **Delete**.
3. A dialog box appears. Tap **Delete** to confirm the deletion.

To delete multiple folders and/or files:

1. Select the files you want to share.
2. Tap the More icon.
3. Tap **Delete**.
4. A dialog box appears. Tap **Delete** to confirm the deletion.

Viewing file and folder information

To view folder and file information:

1. Tap the Actions icon next to a folder or file.
2. Tap the Info icon and view information:

File	Folder
File Type	—
Size	—
Location	Location
Date Modified	Date Modified

3. Tap the Back arrow to return to the Main Menu.

Renaming a folder or file

To rename a folder or file:

1. Select the folder or file you want to rename.
2. Tap the More icon.
3. Tap [Rename](#).
4. Use the virtual keyboard to enter a new name for the folder or file.
5. Tap [Rename](#).

Viewing notifications

You can review a list of SSD Touch system notifications.

1. Tap the Navigation icon.
2. Tap [Notifications](#).
3. Notifications are ordered by date. To change whether dates are ascending or descending, tap the More icon and select [Ascending](#) or [Descending](#).
4. To clear the notifications list, tap the More icon and select [Clear All](#).
5. Tap the Back arrow to return to the Main Menu.

Viewing configuration settings

To view SSD Touch configuration settings:

1. Tap the Navigation icon.
2. Tap [Configuration Settings](#).
3. Select from the following options:

Ultra Touch Setting	Description
Rename	Rename device.
User Manual	View device documentation.
App Setting	Description
About	View Seagate policies.
Share usage data	Allow SSD Touch to periodically send anonymous usage statistics that help us improve your experience with Seagate Ultra Touch and the SSD Touch app.
App version	View your current SSD Touch version and initiate a manual app update when available.
Report a problem	Access the online support page for help troubleshooting problems. If you're experiencing a frequent issue, you can send a log report to the SSD Touch development team.

